

## Paper Handling

⇒ 37576


For a complete list of paper that works with your printer, see the Recommended Media List.

[www.xerox.com/rmlna](http://www.xerox.com/rmlna) (U. S. and Canada)


[www.xerox.com/rmleu](http://www.xerox.com/rmleu) (Europe)

For details about trays and paper, refer to the *User Guide*.

## Loading Paper




2



Confirm or change size, type, and weight as needed.

3



For the best results, fan the edges of the paper. Adjust the guides to fit the paper size. Do not load paper above the maximum fill line.

When printing, select options in the printer driver.

## Paper Orientation

⇒ 37577

