




Note the printer IP address on the touch screen. If the IP Address does not appear in the top of the touch screen, press **Home**, touch **Device** > **About** then scroll to check the IP Address.

2



In a Web browser, type the printer IP address, then press **Enter** or **Return**.

3



Click the **Scan** tab.